

# BATCH MANUFACTURING RECORD

## STM Hydrogen Desorption Lithography Process

Batch Number:	_____	Date Started:	_____
Device ID:	1	Target Completion:	_____
Sample:	_____	Actual Completion:	_____
Primary Operator:	_____	QC Review:	_____

### Step 1: Sample Preparation & Cleaning

Operator Initials:	Start Time:	End Time:	2025-11-10T12:32:42.529080
--------------------	-------------	-----------	----------------------------

#### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Cleaning Method	Acetone + IPA ultrasonic	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Inspection Result	No visible contamination	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

#### Quality Checks:

✓	Check Description	Pass/Fail
<input checked="" type="checkbox"/>	Surface cleanliness	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input checked="" type="checkbox"/>	No visible contamination	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

<b>Notes / Observations:</b>

Completed by:	Date/Time: 2025-11-10T12:32:42.529080
---------------	---------------------------------------

Verified by:	Date/Time:
--------------	------------

### Step 2: Sample Loading & Pumpdown

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

**Process Parameters:**

Parameter	Specification	Actual Value	Within Spec?
Load Time	As required	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Base Pressure (Torr)	< 1x10■■	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

**Quality Checks:**

✓	Check Description	Pass/Fail
<input checked="" type="checkbox"/>	Loadlock pressure < 5x10■■ mbar	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

**<b>Notes / Observations:</b>**

Completed by:	Date/Time:
Verified by:	Date/Time:

### Step 3: Degas

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

#### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Temperature (°C)	200-300	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Duration (min)	30-120	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Pressure During (Torr)	< 5x10 <sup>-6</sup>	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

#### Quality Checks:

✓	Check Description	Pass/Fail
<input type="checkbox"/>	Target temperatures reached	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input type="checkbox"/>	Pressure stable	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

**<b>Notes / Observations:</b>**

Completed by:	Date/Time:
Verified by:	Date/Time:

### Step 4: Flash Clean

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

#### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Flash Temperature (°C)	1200 ± 50	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Flash Duration (s)	5-10	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Flash Current (A)	Per calibration	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

#### Quality Checks:

✓	Check Description	Pass/Fail
<input type="checkbox"/>	Temperature profile correct	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input type="checkbox"/>	Surface reconstructed	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

**<b>Notes / Observations:</b>**

--	--

<b>Completed by:</b>	<b>Date/Time:</b>
<b>Verified by:</b>	<b>Date/Time:</b>

## Step 5: H-Termination

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Temperature (°C)	330 ± 5	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
H Pressure (Torr)	1x10 <sup>-6</sup>	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Dose Time (s)	As required	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Dose (Langmuirs)	~ 1000 L	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓	Check Description	Pass/Fail
<input checked="" type="checkbox"/>	Temperature 330°C ± 5°C	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input checked="" type="checkbox"/>	Uniform H coverage	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

<b>Notes / Observations:</b>

Completed by:	Date/Time:
Verified by:	Date/Time:

## Step 6: STM Imaging Pre-Lithography

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Scan Area (nm)	As required	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Bias (V)	Typically -2.0 to +2.0	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Setpoint (pA)	10-100	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓	Check Description	Pass/Fail
<input checked="" type="checkbox"/>	Atomically resolved	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input checked="" type="checkbox"/>	Terrace quality acceptable	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

**<b>Notes / Observations:</b>**

<b>Completed by:</b>	<b>Date/Time:</b>
<b>Verified by:</b>	<b>Date/Time:</b>

## Step 7: STM Lithography

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Pattern Design	Per device spec	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Litho Voltage (V)	6-8 V typical	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Desorption Speed	Per pattern	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓	Check Description	Pass/Fail
<input checked="" type="checkbox"/>	Pattern complete	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input checked="" type="checkbox"/>	Line quality good	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

<b>Notes / Observations:</b>

Completed by:	Date/Time:
Verified by:	Date/Time:

## Step 8: Post-Litho STM Imaging

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Scan Area (nm)	Cover pattern	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Feature Measurements	Within design spec	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓	Check Description	Pass/Fail
<input checked="" type="checkbox"/>	Pattern verified	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input checked="" type="checkbox"/>	Dimensions within spec	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

<b>Notes / Observations:</b>

--	--

<b>Completed by:</b>	<b>Date/Time:</b>
<b>Verified by:</b>	<b>Date/Time:</b>

## Step 9: Dopant Dosing (PH<sub>3</sub> or AsH<sub>3</sub>)

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Dopant Species	PH <sub>3</sub> or AsH <sub>3</sub>	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Dose Pressure (Torr)	1×10 <sup>-6</sup> to 1×10 <sup>-5</sup>	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Dose Duration (s)	As required	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Dose (Langmuirs)	Per design	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓	Check Description	Pass/Fail
<input checked="" type="checkbox"/>	Dose within spec	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input checked="" type="checkbox"/>	Pressure stable during dose	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

<b>Notes / Observations:</b>

Completed by:	Date/Time:
Verified by:	Date/Time:

## Step 10: Dopant Incorporation

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Temperature (°C)	350 ± 5	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Duration (s)	60-180	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Thermal Budget Δ (°C·s)	Track cumulative	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓	Check Description	Pass/Fail
<input checked="" type="checkbox"/>	Temperature 350°C ± 5°C	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input checked="" type="checkbox"/>	Surface morphology acceptable	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

**<b>Notes / Observations:</b>**

<b>Completed by:</b>	<b>Date/Time:</b>
<b>Verified by:</b>	<b>Date/Time:</b>

## Step 11: Post-Incorporation STM Imaging

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Scan Area (nm)	Cover pattern	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Pattern Visibility	Features visible	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓ Check Description	Pass/Fail
<input type="checkbox"/> Pattern still visible	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input type="checkbox"/> No major defects	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

**<b>Notes / Observations:</b>**

Completed by:	Date/Time:
Verified by:	Date/Time:

## Step 12: Silicon Overgrowth - RT Phase

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Growth Temp (°C)	25 (RT)	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Growth Time (s)	Per rate	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Target Thickness (nm)	~ 7 nm	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓ Check Description	Pass/Fail
<input type="checkbox"/> Growth rate calibrated	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input type="checkbox"/> Uniform coverage	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

**<b>Notes / Observations:</b>**

--	--

<b>Completed by:</b>	<b>Date/Time:</b>
<b>Verified by:</b>	<b>Date/Time:</b>

## Step 13: Silicon Overgrowth - RTA Anneal

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Anneal Temp (°C)	550	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Anneal Time (s)	60	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Thermal Budget Δ (°C·s)	Track cumulative	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓	Check Description	Pass/Fail
<input type="checkbox"/>	Temperature profile correct	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input type="checkbox"/>	No delamination	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

<b>Notes / Observations:</b>

Completed by:	Date/Time:
Verified by:	Date/Time:

## Step 14: Silicon Overgrowth - LTE Phase

Operator Initials:	Start Time:	End Time:
--------------------	-------------	-----------

### Process Parameters:

Parameter	Specification	Actual Value	Within Spec?
Growth Temp (°C)	250	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Growth Time (s)	Per rate	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Total Thickness (nm)	~ 20 nm	_____	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

### Quality Checks:

✓	Check Description	Pass/Fail
<input type="checkbox"/>	Target thickness achieved	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail
<input type="checkbox"/>	Final thermal budget acceptable	<input checked="" type="checkbox"/> Pass <input type="checkbox"/> Fail

<b>Notes / Observations:</b>

--	--

<b>Completed by:</b>	<b>Date/Time:</b>
<b>Verified by:</b>	<b>Date/Time:</b>

## FINAL REVIEW AND APPROVAL

<b>&lt;b&gt;Review Item&lt;/b&gt;</b>	<b>&lt;b&gt;Complete&lt;/b&gt;</b>	<b>&lt;b&gt;Initials&lt;/b&gt;</b>
All process steps completed as specified	<input checked="" type="checkbox"/>	_____
All quality checks passed	<input checked="" type="checkbox"/>	_____
All parameters within specification	<input checked="" type="checkbox"/>	_____
All deviations documented and approved	<input checked="" type="checkbox"/>	_____
All required signatures obtained	<input checked="" type="checkbox"/>	_____
LabVIEW process files linked/attached	<input checked="" type="checkbox"/>	_____
STM scan files linked/attached	<input checked="" type="checkbox"/>	_____

### Final Approvals:

#### Quality Control Review:

Signature: \_\_\_\_\_

Date: \_\_\_\_\_

Printed Name: \_\_\_\_\_

#### Process Engineer Review:

Signature: \_\_\_\_\_

Date: \_\_\_\_\_

Printed Name: \_\_\_\_\_

#### Principal Investigator Approval:

Signature: \_\_\_\_\_

Date: \_\_\_\_\_

Printed Name: \_\_\_\_\_

*This batch manufacturing record must be completed in its entirety and approved by all designated reviewers before the device can proceed to electrical testing or further processing.*